


LEGENDA LEGEND LEGENDE LEGENDE

B1	SELETTORE ZYKLUSWAHLSCHALTER	SELECTEUR SELECTOR
C	CONTATTORE SCHLTSCUTZ	CONTACTEUR CONTACTOR
LV	SPIA MACCHINA IN TENSIONE MACHINE LIVE WARNING LAMP	MASCHINE UNTER SPANNUNG-LAMPE LAMPE APPAREIL SOUS TENSION
LF	SPIA MACCHINA IN FUNZIONE MACHINE ON WARNING LAMP	MASCHINE IN BETRIEB-LAMPE LAMPE MACHINE EN FONCTION
MI	MICROINTERRUTTOR TUER	MICROINTERRUPTEUR MICROSWITCH
M0	MORSETTIERA MAIN TERMINAL BOARD	KLEMMENBRETT BOITE DE CONNECTION
R	RESISTENZA VASCA TANKHEIZKOERPER	RESISTANCE CUVE TANK HEATER
T	TERMOSTATO THERMOSTAT	THERMOSTAT THERMOSTAT
TS	TERMOSTATO SICUREZZA SICHERHEITSTHERMOSTAT	THERMOSTAT DE SICURITE SAFETY THERMOSTAT

286917
296620

11 - 11 - 08

230V ~ 50 Hz



COLLEGARE IL CAVO DI ALIMENTAZIONE AD UN SEZIONATORE A PARETE - RELIER LE CABLE D'ALIMENTATION A UN INTERRUPTEUR MURAL - CONNECT THE POWER-SUPPLY CABLE WITH A WALL DISCONNECTOR - BAUSEITS IST EIN HAUPTSCHALTER ZU INSTALLIEREN