



LEGENDA		LEGEND	LEGENDE	LEGENDE
B <sub>1,2</sub>	SELETTORE ZYKLUSWAHLSCHALTER	CONTACTEUR SELECTEUR	CONTACTEUR SELECTEUR	
C <sub>1,2</sub>	CONTATTORE SCHALTSCHUTZ	CONTACTEUR CONTACTOR	CONTACTEUR CONTACTOR	
LV	SPIA MACCHINA IN TENSIONE MACHINE LIVE WARNING LAMP	MACHINE UNDER SPANNUNG-LAMPE LAMPE APPAREIL SOUS TENSION	MACHINE UNDER SPANNUNG-LAMPE LAMPE APPAREIL SOUS TENSION	
LF	SPIA MACCHINA IN FUNZIONE MACHINE ON WARNING LAMP	MACHINE IN BETRIEB-LAMPE LAMPE MACHINE EN FONCTION	MACHINE IN BETRIEB-LAMPE LAMPE MACHINE EN FONCTION	
MI <sub>1,2</sub>	MICROINTERRUTTORE TUER	MICROINTERRUPTEUR MICROSWITCH	MICROINTERRUPTEUR MICROSWITCH	
M0	MORSETTIERA MAIN TERMINAL BOARD	KLEMMENBRETT BOÎTE DE CONNECTION	KLEMMENBRETT BOÎTE DE CONNECTION	
R <sub>1,2</sub>	RESISTENZA VASCA TANKHEIZKOERPER	RESISTANCE CUVE TANK HEATER	RESISTANCE CUVE TANK HEATER	
T <sub>1,2</sub>	TERMOSTATO THERMOSTAT	THERMOSTAT THERMOSTAT	THERMOSTAT THERMOSTAT	
TS <sub>1,2</sub>	TERMOSTATO SICUREZZA SICHERHEITSTHERMOSTAT	THERMOSTAT DE SICURITE SAFETY THERMOSTAT	THERMOSTAT DE SICURITE SAFETY THERMOSTAT	
286922 286925 296960			11 - 11 - 08	

COLLEGARE IL CAVO DI ALIMENTAZIONE AD UN SEZIONATORE A PARETE - RELIER LE CABLE D'ALIMENTATION A UN INTERRUPTEUR MURAL - CONNECT THE POWER-SUPPLY CABLE WITH A WALL DISCONNECTOR - BAUSEITS IST EIN HAUPTSCHALTER ZU INSTALLIEREN